

## Instructions for mounting 2011 Wolfman Expedition Dry and Teton Saddlebag to RotoPax equipped Side Racks.

This kit contains the following:

Quantity	Description
4	Extensions Straps

These instructions are an **Addendum** to the Mounting instructions Wolfman Expedition Dry and Teton Saddlebag to the Wolfman and Backroads Moto Side Racks.

This kit is only intended to be used only with the Wolfman Expedition Dry Saddlebags and Teton Saddlebags and the RotoPax mounted side rack.

Read and understand these instructions before touching your bike, rack or a wrench.

Rear View of Saddle Bag RotoPax equipped bike. Fig1  
Fig 1



**\*\*Make Sure to remove the RotoPax Fuel Pack\*\***

1. Thread Extension Straps through the loops on the Wolfman side Rack As shown. Fig 2 (The Rack is Equipped with the Side Rack Plate and RtotPax Mount installed. But without the Fuel Pack.)

Fig 2



2. Thread the Metal D-Ring Through the Webbing opening as shown. Fig 3&4

Fig 3



Fig 4



3. Repeat steps 1 and 2 for the other three rack loops. Fig 5

Fig 5



4. Mount RotoPax. Fig 6&7  
Fig 6 (RotoPax and Extension Straps)



Fig 7



5. Attach Wolfman Expedition Dry or Teton Saddlebags as you would to a Plain Rack. Fig 8&9  
Rear View Fig 8



Front View Fig 9



\*\*\*\*Note: When Expedition Dry and or Teton Saddlebags are NOT being used, Remove the Extension Straps from the loops on the side rack, by reversing the steps. If your straps are dirty wetting them will soften the webbing making them easier to remove.

If you have any questions call or email us at 800/535-8131 or [info@wolfmanluggage.com](mailto:info@wolfmanluggage.com).