

Mounting Instructions for Wolfman and Backroads Moto Side Rack Cross Brace BMW F650-800 Twin

This kit contains the following:

Quantity	Description
1	Cross Brace BMW F650-800 Twin
2	8mm x 1.25 x 20mm Button Head Bolts
2	8mm Washers
2	8mm Lock Nuts

Tools needed

5mm Hex Wrench

13mm Box End Wrench

Read and understand these instructions prior to installation!

1. Place one 8mm x 1.25 x 20mm button head bolt (no washer) through rack flange and through cross brace tab, thread on lock nut with washer. Repeat for other side. Tighten Snug.



If you have any questions call or email Berg Briggs at:
1-307-690-0452
berg@brmoto.com