

# Mounting Instructions for mounting 2010 Wolfman and Backroads Moto Side Racks

KLR 650 87-07

This kit contains the following:

Quantity	Description
1	Left rack
1	Right rack
2	8mmx55mm socket head
4	8mmx35mm socket head
6	8mm washers (small)

## Tools needed

BLUE or a Medium Strength Locktight or thread locker

5mm hex wrench

6mm hex wrench

These Racks are intended to be used only with the Wolfman Expedition Dry Saddlebags and Teton Saddlebags.

Read and understand these instructions before touching your bike, rack or a wrench

## Be Sure To Locktight All Bolt's

### Right side rack

1. Remove passenger peg and forward most mounting bolt for top luggage rack.
2. Apply locktight on one 8mmx55mm socket head bolt with washer, insert through upper rack mount and thread into top mount hole. DO NOT TIEGHTEN. See Fig 1



FIG 1

3. Apply locktight to two 8mmx35mm socket head bolts with washers, insert bolts through lower rack mount then through passenger peg and thread into sub frame. See Fig 2



FIG 2

4. Tighten all mounting bolts on right side.

#### **Left side rack**

1. Remove passenger peg and forward most mounting bolt for top luggage rack.
2. Apply locktight on one 8mmx55mm socket head bolt with washer, insert through upper rack mount and thread into top mount hole. DO NOT TIEGHTEN. See Fig 3



FIG 3

3. Apply locktight to two 8mmx35mm socket head bolts with washers, insert bolts through lower rack mount then through passenger peg and thread into sub frame See Fig 4



FIG 4

4. Tighten all mounting bolts on right side.



If you have any questions call or email Berg Briggs at:  
1-307-690-0452  
berg@brmoto.com