

# Mounting Instructions for mounting 2010 Wolfman and Backroads Moto Side Racks

KTM 950-990 ADV

This kit contains the following:

Quantity	Description
1	Left rack
1	Right rack
2	8mmx80mm socket head
4	8mmx30mm flat head
2	8mmx80mm flat head
2	8mmx55mm flat head
2	8mm washer (small)
2	3/4x1 spacer (aluminum 90 deg chafer)
2	3/4x1/4 spacer aluminum
2	3/4x13/4 spacer steel

## Tools needed

BLUE or a Medium Strength Locktight or thread locker

5mm hex wrench

6mm hex wrench

These Racks are intended to be used only with the Wolfman Expedition Dry Saddlebags and Teton Saddlebags.

Read and understand these instructions before touching your bike, rack or a wrench

### Be Sure To Locktight All Bolt's

1. Remove top luggage plate and grab handles (grab handles will not be reused)
2. Remove passenger pegs.
3. Apply locktight on two 8mmx55mm flat head bolts, place bolts through back two top luggage plate mount holes and through 3/4x1 aluminum spacers. See fig 1



FIG 1

### Right side rack

1. Apply locktight to one 8mmx80mm socket head bolt with washer, place bolt through mid rack mount and 3/4x1 3/4 steel spacer, thread into threaded hole in number plat. DO NOT TIEGHTEN See Fig 2



FIG 2

2. Apply locktight to two 8mmx30mm flat head bolts, place one through top passenger peg hole and through lower rack mount, loosely start. See Fig 3
3. Place 2<sup>nd</sup> 8mmx30mm flat head in lower passenger peg mount hole and put one 3/4x1/4 spacer between sub frame and passenger peg, thread bolt in, leave loose. See Fig 3



FIG 3

4. Apply locktight to one 8mmx80mm flat head and place thought top luggage plate and top rack mount. See Fig 4



FIG 4

### Left side rack

1. Apply locktight to one 8mmx80mm socket head bolt with washer, place bolt through mid rack mount and 3/4x1 3/4 steel spacer, thread into threaded hole in number plat. DO NOT TIEGHTEN See Fig 5



FIG 5

2. Apply locktight to two 8mmx30mm flat head bolts, place one through top passenger peg hole and through lower rack mount, loosely start. See Fig 6



FIG 6

3. Place 2<sup>nd</sup> 8mmx30mm flat head in lower passenger peg mount hole and put one 3/4x1/4 spacer between sub frame and passenger peg, thread bolt in, leave loose
4. Apply locktight to one 8mmx80mm flat head and place thought top luggage plate and top rack mount. See Fig 7



FIG 7

5. Tighten all bolts

If you have any questions call or email Berg Briggs at:  
1-307-690-0452  
berg@brmoto.com