

# Mounting Instructions for Wolfman and Backloads Moto Side Racks Cross Brace KTM 950-990 Cross Brace

This kit contains the following:

Quantity	Description
1	Cross Brace KTM 950-990
2	8mm x 1.25 x 20mm Round Head Bolt
2	8mm Lock Nut
2	8mm Washer (small)
1	6mm x 1 x 20mm Flat Head Bolt
1	6mm Lock Nut
1	6mm Washer Small
1	5/8" Clamp

## Tools needed

5 mm Hex Wrench

4 mm Hex Wrench

10mm Box End Wrench or Socket

13mm Box End Wrench or Socket

## Read and understand these instructions prior to installation!

1. Place one 8mm x 1.25 x 20mm button head bolt (no washer) through rack flange and through cross brace tab, thread on lock nut with washer. Repeat for other side. FIG 1

FIG 1



2. Install the 5/8" clamp onto cross brace. FIG 2
3. Using one 6mm x 1 x 20mm flat head bolt, washer and nut; attach clamp and cross brace onto one of the bottom license plate holes in fender OR drill a new hole in fender. Align with mounting hole in clamp.

FIG 2



FIG 3



If you have any questions call or email Berg Briggs at:  
1-307-690-0452  
berg@brmoto.com